

Hydrogen Peroxide CHEMets® Kit

K-5510/R-5510: 0 - 0.8 & 1 - 10 ppm

Safety Information

Read SDS (available at www.chemetrics.com) before performing this test procedure. Wear safety glasses and protective gloves.

Test Procedure

1. Fill the sample cup to the 25 mL mark with the sample to be tested (fig. 1).
2. Place the CHEMet ampoule, tip first, into the sample cup. Snap the tip. The ampoule will fill leaving a bubble for mixing (fig. 2).
3. To mix the ampoule, invert it several times, allowing the bubble to travel from end to end.
4. Dry the ampoule. Obtain a test result **between 30 seconds and 1 minute** after snapping the tip.
5. Obtain a test result using the appropriate comparator.

a. **Low Range Comparator (fig. 3):**

Place the ampoule, flat end first, into the comparator. Hold the comparator up toward a source of light and view from the bottom. Rotate the comparator until the best color match is found.

b. **High Range Comparator (fig. 4):**

Place the ampoule between the color standards until the best color match is found.




Figure 1




Figure 2




Figure 3




Figure 4

Test Method

The Hydrogen Peroxide CHEMets®¹ test method employs the ferric thiocyanate chemistry.² In an acidic solution, hydrogen peroxide oxidizes ferrous iron. The resulting ferric iron reacts with ammonium thiocyanate to form ferric thiocyanate, a red-orange colored complex, in direct proportion to the hydrogen peroxide concentration.

Ferric iron and peracetic acid (PAA) will produce high test results. Cupric copper also interferes with the test.

Testing for peroxide in the presence of PAA or cupric copper requires a modified test procedure. Contact technical@chemetrics.com for more information.

1. CHEMets is a registered trademark of CHEMetrics, LLC U.S. Patent No. 3,634,038
2. APHA Standard Methods, Method 4500-H₂O₂ B-2020

Visit www.chemetrics.com to view product demonstration videos.
Always follow the test procedure above to perform a test.



www.chemetrics.com
4295 Catlett Road, Midland, VA 22728 U.S.A.
Phone: (800) 356-3072; Fax: (540) 788-4856
E-Mail: orders@chemetrics.com

Jan. 23, Rev. 13